

CHEVY TRUCK

Advanced Design 1947 Thru 1955* Series I

Vintage Air
SUREFIT
Systems



And GMC 1947 Thru 1953

NEW!
Now Featuring
Our Gen IV
Technology



Complete Gen IV SureFit kit for
Advanced Design Chevy/GMC Trucks

Gen IV SureFit™ System Features:

- Fly-By-Wire fully electronic servo controls with no cables or capillary tube to route.
- Infinite "just right temperature" air blending.
- Infinite blower fan speed adjustment.
- High-volume dehumidified defrost.
- Separate high-capacity aluminum plate and fin cooling coil.
- Copper/brass CuproBraze™ parallel flow heater coil.
- Mounts behind the dash.
- Kit includes 3-knob controls.
- Flat steel firewall cover panel.
- Replacement molded glove box (reduced capacity).

NOTE: *

These kits fit Series I early season 1955 "Advanced Design" Chevy Trucks. Chevrolet ended the "Advanced Design" model trucks in mid-1955.

Complete Kits - Gen IV SureFit

- 941852** 1947-49 Chevy Complete Kit V8 Swap
- 941855** 1947-49 Chevy Complete Kit with Standard 6-Cyl Bracket
- 941858** 1947-49 Chevy Complete Kit with Deluxe 6-Cyl Bracket
- 941853** 1950-53 Chevy Complete Kit V8 Swap
- 941856** 1950-53 Chevy Complete Kit with Standard 6-Cyl Bracket
- 941859** 1950-53 Chevy Complete Kit with Deluxe 6-Cyl Bracket
- 941854** 1954-55 Chevy Complete Kit V8 Swap
- 941857** 1954-55 Chevy Complete Kit with Standard 6-Cyl Bracket
- 941860** 1954-55 Chevy Complete Kit with Deluxe 6-Cyl Bracket

NOTE: Deluxe 6 Cylinder bracket part number 142401 shown page 67 (includes new double groove harmonic balancer).

Evaporator Kits - Gen IV SureFit (See Page 13)

- 754561** 1947-49 Chevy Evaporator Kit (V8 or 6-Cylinder)
- 754562** 1950-53 Chevy Evaporator Kit (V8 or 6-Cylinder)
- 754563** 1954-55 Chevy Evaporator Kit (V8 or 6-Cylinder)

NOTE:

1. Some installations may require additional engine pulleys not included with kits. You must provide pulleys, V-belts, heater hose and refrigerant. See page 81 for Chevy pulleys.



Vintage Air SureFit system evaporators install completely inside the cab for a clean, original looking engine compartment. Firewall plate mounts to original holes.



1948-55 Chevy truck dash with SureFit kit.

NOTES:

2. We recommend using our heavy-duty fan blade and a fan shroud. **32042-VFF** 1947-54 Chevy Truck Fan Shroud (V8)
3. SureFit systems may interfere with some OEM radios or in-dash speakers.

CUSTOMER SERVICE TEAM

Ramon Barrientes has been involved in the automotive industry for over 17 years. Just like all of us here at Vintage Air, Ramon is a total car enthusiast. Ramon is shown here with his "Double Nickle" '55 Chevy sedan featuring polished Americans, hot red paint and a complete Vintage Air system.

